

PrintCloud Plus



It is the reader's responsibility when discussing the information contained this document to maintain a level of confidentiality that is in the best interest of Ricoh USA INC and its member companies.

NO PART OF THIS DOCUMENT MAY BE REPRODUCED IN ANY FASHION AND/OR DISTRIBUTED WITHOUT THE PRIOR PERMISSION OF RICOH USA INC

All product names, partner's brands and their products, domain names or product illustrations, including desktop images used in this document are trademarks, registered trademarks or the property of their respective holders and should be noted as such.

Any trademark or registered trademark found in this support manual is used in an informational or editorial fashion only and for the benefit of such companies. No such use, or the use of any trade name, or web site is intended to convey endorsement or other affiliation with Ricoh products.

Copyright © 2019-2026 Ricoh USA INC

Table of Contents

Table of Contents	4
1 Preface	5
2 Introduction.....	6
3 How to Submit Print Job?	7
4 How to Submit Print Job from PrintCloud Virtual Print Driver?	8
5 Operation of PrintCloud Workflow Application	10
Print Settings.....	14
6 Configuration of default Print Settings by Administrator	18
7 Limitations.....	20
PrintCloud Plus Limitation	20
File Conversion Limitations.....	20
Workplace Limitations.....	20
General Limitations	21
8 Appendix.....	22
Supported File Types	22

1 Preface

This guide provides the details on how to use the workflow PrintCloud Plus

About This Guide

This guide is divided into following primary sections:

1. Introduction

This section lays the foundation for understanding the workflow specification

2. How to Submit Print Job

This section describes how to submit Print job and receive Release Code.

3. Operation of PrintCloud Plus Application

This section contains step-by-step instructions on how to operate PrintCloud Plus application on MFP Operation panel

4. Configuration of default Print Settings by Administrator

This section describes how administrator can set default values for print settings to all users.

5. Limitations

Product Limitations

6. Appendix

This section contains additional reference materials

Note: The operation panel screen shot images and Workplace images provided in this document are for illustrative purposes only. These images may not reflect the exact image you experience on your multi-functional printer (MFP device).

2 Introduction

What is PrintCloud Plus workflow?

PrintCloud Plus is a workflow application developed on Ricoh Smart Integration Platform.

This workflow enables to print documents, which are submitted to PrintCloud through Email (Email body and attachment) or PrintCloud Virtual Print Driver. Sender's Email should be same as your RICOH Smart Integration Account Email.

All the jobs submitted through this Email and which are converted successfully are listed in the PrintCloud Plus workflow view. Users can select the job and print

PrintCloud Email: print@ricohprintcloud.com

3 How to Submit Print Job?


Email: print@ricohprintcloud.com

Send Email to above email address from your RICOH Smart Integration Login Email address. PrintCloud service will convert Email body and attachment as PDF file. Service will reply to sender's email address with 'Release Code' for each attachment and also email body, with thumbnails as shown below.


However, Release Codes are not necessary to print if the PrintCloud Plus workflow is used.



4 How to Submit Print Job from PrintCloud Virtual Print Driver?



Right Click on 'PrintCloud' ICON in system Tray. Please 'Settings' from the Menu.



For Print Jobs to be available in PrintCloud Plus Job list, Please enter the **Email address with which you login to RICOH Smart Integration.**

Note: For users (RICOH internal & Dealers) who have multiple RICOH Smart Integration accounts, by using the same Gmail address like:

- abcd+unique1@gmail.com
- abcd+unique2@gmail.com

Please enter your actual gmail address:

Which is: abcd@gmail.com

Do not enter '+.....'. This is not supported. You can access your print jobs from all of your RSI Tenants which uses your Gmail address to login.

5 Operation of PrintCloud Plus Workflow Application


Smart Integration MFP BrowserNX URL

<https://www.na.smart-integration.ricoh.com/si-apps/pub/index.html>

Ricoh Smart Integration Initial Login

Above URL is available as Bookmark ICON on MFP. Very first time, administrator need to login to the site either using Tenant ID, User ID and Password or Email address and password.

Option 1: Login with Tenant ID



The screenshot shows a login interface titled "Login to RICOH Smart Integration". At the top, there is a dropdown menu with "Login with Tenant ID" selected. Below this are three input fields: "Tenant ID", "User ID", and "Password". At the bottom of the form is a blue "Login" button.

Option 2: Login with Email Address

← Login to RICOH Smart Integration

Login with Email Address

Email Address user@gmail.com

Password

Login

After administrator login subscribed application will be displayed

Home List


- Device Enhancement Add-On
- Auto Name and Route-Meta
- Legal Add-On
- Healthcare Add-On
- Smart Integration Connectors
- SDCA Test Package
- Smart Integration Essentials
- Local Folder
- Box

Add-On


Scan to Me

Login

Use the Home List button to Select 'Device Enhancement Add-On'.




Touch on the Print Cloud Plus. Login Screen is displayed. Use your preferred login method to login to RICOH Smart Integration



'Print Jobs' List is displayed

Touch on 'Check box' next to the Print Job in the list to select. Up to 10 jobs can be selected at a time




Note:


1. Jobs printed will be removed from job list immediately and will be deleted during daily purge cycle.
2. Not Printed Jobs will be automatically deleted after 3 days from submission date.

Touch on 'Start' button to Print selected Jobs





Print Settings






Touch on 'Print Settings' to display Print Settings Screen



Note: Administrator can force default settings to all users. Refer to Next Section for Details

Print Settings	Available Options
<p>Print Color Mode</p>	
<p>Copies</p>	<p>Range 1-999</p> 
<p>Sides</p>	
<p>Input Tray</p>	
<p>Collate/Stacking</p>	



	 <p>Print Settings</p> <p>Full Color 1 1 Sided</p> <p>Input Tray: Auto Tray Select</p> <p>Rotating Collate N-Up: Off</p> <p>Shift Collate Collate: Off</p> <p>Punch: Off</p> <p>Start</p>
N-Up	 <p>N-Up</p> <p>Off 2 Pages</p> <p>4 Pages 6 Pages</p> <p>8 Pages 9 Pages</p> <p>16 Pages</p> <p>Start</p>
Paper Size	 <p>Paper Size</p> <p>Auto A4</p> <p>A5 JIS B5</p> <p>Double postcard (Japan) SRA4</p> <p>Custom Letter</p> <p>Executive C6</p> <p>Paper Size</p> <p>Envelope (Youchou 3 (Youkei 0)) Envelope (Youkei 4)</p> <p>A3 (Horizontal) A4 (Horizontal)</p> <p>A5 (Horizontal) A6 (Horizontal)</p> <p>JIS B4 (Horizontal) JIS B5 (Horizontal)</p> <p>JIS B6 (Horizontal) Double postcard (Japan) (Horizontal)</p> <p>Paper Size</p> <p>Postcard (Japan) (Horizontal) SRA3 (Horizontal)</p> <p>SRA4 (Horizontal) 11 x 17 (Horizontal)</p> <p>Legal (Horizontal) Letter (Horizontal)</p> <p>Invoice (Horizontal) 12 x 18 (Horizontal)</p> <p>C6 (Horizontal) Envelope (Youchou 3 (Youkei 0)) (Horizontal)</p> <p>Start</p>

	<div data-bbox="808 142 1417 476"> <p>← Paper Size</p> <table border="1"> <tbody> <tr> <td><input type="radio"/> Legal (Horizontal)</td> <td><input type="radio"/> Letter (Horizontal)</td> </tr> <tr> <td><input type="radio"/> Invoice (Horizontal)</td> <td><input type="radio"/> 12 x 18 (Horizontal)</td> </tr> <tr> <td><input type="radio"/> C6 (Horizontal)</td> <td><input type="radio"/> Envelope (Youchou 3 (Youkei 0)) (Horizontal)</td> </tr> <tr> <td><input type="radio"/> Envelope (Youkei 4) (Horizontal)</td> <td><input type="radio"/> Envelope (Japan: Choukei 3) (Horizontal)</td> </tr> <tr> <td><input type="radio"/> Envelope (Japan: Choukei 4) (Horizontal)</td> <td><input type="radio"/> Envelope (Japan: Kakukei 2) (Horizontal)</td> </tr> </tbody> </table> <p>Start</p> </div>	<input type="radio"/> Legal (Horizontal)	<input type="radio"/> Letter (Horizontal)	<input type="radio"/> Invoice (Horizontal)	<input type="radio"/> 12 x 18 (Horizontal)	<input type="radio"/> C6 (Horizontal)	<input type="radio"/> Envelope (Youchou 3 (Youkei 0)) (Horizontal)	<input type="radio"/> Envelope (Youkei 4) (Horizontal)	<input type="radio"/> Envelope (Japan: Choukei 3) (Horizontal)	<input type="radio"/> Envelope (Japan: Choukei 4) (Horizontal)	<input type="radio"/> Envelope (Japan: Kakukei 2) (Horizontal)										
<input type="radio"/> Legal (Horizontal)	<input type="radio"/> Letter (Horizontal)																				
<input type="radio"/> Invoice (Horizontal)	<input type="radio"/> 12 x 18 (Horizontal)																				
<input type="radio"/> C6 (Horizontal)	<input type="radio"/> Envelope (Youchou 3 (Youkei 0)) (Horizontal)																				
<input type="radio"/> Envelope (Youkei 4) (Horizontal)	<input type="radio"/> Envelope (Japan: Choukei 3) (Horizontal)																				
<input type="radio"/> Envelope (Japan: Choukei 4) (Horizontal)	<input type="radio"/> Envelope (Japan: Kakukei 2) (Horizontal)																				
Staple	<div data-bbox="808 501 1417 835"> <p>← Staple</p> <table border="1"> <tbody> <tr> <td><input type="radio"/> 2 at Left</td> <td><input type="radio"/> 2 at Right</td> </tr> <tr> <td><input type="radio"/> 2 at Top</td> <td><input type="radio"/> Saddle Stitch</td> </tr> <tr> <td><input type="radio"/> Top Left</td> <td><input type="radio"/> Top Left Slant</td> </tr> <tr> <td><input type="radio"/> Top Right</td> <td><input type="radio"/> Top Right Slant</td> </tr> <tr> <td><input type="radio"/> Bottom Left</td> <td><input type="radio"/> Bottom Left Slant</td> </tr> </tbody> </table> <p>Start</p> </div>	<input type="radio"/> 2 at Left	<input type="radio"/> 2 at Right	<input type="radio"/> 2 at Top	<input type="radio"/> Saddle Stitch	<input type="radio"/> Top Left	<input type="radio"/> Top Left Slant	<input type="radio"/> Top Right	<input type="radio"/> Top Right Slant	<input type="radio"/> Bottom Left	<input type="radio"/> Bottom Left Slant										
<input type="radio"/> 2 at Left	<input type="radio"/> 2 at Right																				
<input type="radio"/> 2 at Top	<input type="radio"/> Saddle Stitch																				
<input type="radio"/> Top Left	<input type="radio"/> Top Left Slant																				
<input type="radio"/> Top Right	<input type="radio"/> Top Right Slant																				
<input type="radio"/> Bottom Left	<input type="radio"/> Bottom Left Slant																				
Punch	<div data-bbox="808 852 1417 1186"> <p>← Punch</p> <table border="1"> <tbody> <tr> <td><input type="radio"/> GBC Left (Multiple Holes)</td> <td><input type="radio"/> GBC Right (Multiple Holes)</td> </tr> <tr> <td><input type="radio"/> GBC Top (Multiple Holes)</td> <td><input type="radio"/> 4 at Left</td> </tr> <tr> <td><input type="radio"/> 3 at Left</td> <td><input type="radio"/> 1 at Upper Left</td> </tr> <tr> <td><input type="radio"/> 2 at Left</td> <td><input type="radio"/> 4 at Right</td> </tr> <tr> <td><input type="radio"/> 3 at Right</td> <td><input type="radio"/> 2 at Right</td> </tr> </tbody> </table> <p>Start</p> </div> <div data-bbox="808 1194 1417 1528"> <p>← Punch</p> <table border="1"> <tbody> <tr> <td><input type="radio"/> 3 at Left</td> <td><input type="radio"/> 1 at Upper Left</td> </tr> <tr> <td><input type="radio"/> 2 at Left</td> <td><input type="radio"/> 4 at Right</td> </tr> <tr> <td><input type="radio"/> 3 at Right</td> <td><input type="radio"/> 2 at Right</td> </tr> <tr> <td><input type="radio"/> 4 at Top</td> <td><input type="radio"/> 3 at Top</td> </tr> <tr> <td><input type="radio"/> 2 at Top</td> <td><input checked="" type="radio"/> Off</td> </tr> </tbody> </table> <p>Start</p> </div>	<input type="radio"/> GBC Left (Multiple Holes)	<input type="radio"/> GBC Right (Multiple Holes)	<input type="radio"/> GBC Top (Multiple Holes)	<input type="radio"/> 4 at Left	<input type="radio"/> 3 at Left	<input type="radio"/> 1 at Upper Left	<input type="radio"/> 2 at Left	<input type="radio"/> 4 at Right	<input type="radio"/> 3 at Right	<input type="radio"/> 2 at Right	<input type="radio"/> 3 at Left	<input type="radio"/> 1 at Upper Left	<input type="radio"/> 2 at Left	<input type="radio"/> 4 at Right	<input type="radio"/> 3 at Right	<input type="radio"/> 2 at Right	<input type="radio"/> 4 at Top	<input type="radio"/> 3 at Top	<input type="radio"/> 2 at Top	<input checked="" type="radio"/> Off
<input type="radio"/> GBC Left (Multiple Holes)	<input type="radio"/> GBC Right (Multiple Holes)																				
<input type="radio"/> GBC Top (Multiple Holes)	<input type="radio"/> 4 at Left																				
<input type="radio"/> 3 at Left	<input type="radio"/> 1 at Upper Left																				
<input type="radio"/> 2 at Left	<input type="radio"/> 4 at Right																				
<input type="radio"/> 3 at Right	<input type="radio"/> 2 at Right																				
<input type="radio"/> 3 at Left	<input type="radio"/> 1 at Upper Left																				
<input type="radio"/> 2 at Left	<input type="radio"/> 4 at Right																				
<input type="radio"/> 3 at Right	<input type="radio"/> 2 at Right																				
<input type="radio"/> 4 at Top	<input type="radio"/> 3 at Top																				
<input type="radio"/> 2 at Top	<input checked="" type="radio"/> Off																				


Note: Some finishing options like Staple and Punch are available only when appropriate finishing unit is installed with Multifunction Device

6 Configuration of default Print Settings by Administrator


Login to RSI Workplace Site using URL: <https://na.accounts.ricoh.com/portal/login.html> with administrator Credential.




Turn on the Admin Mode (Top Right Corner). Click on 'Applications Settings' ICON



Click on 'Device Enhancement Add-On' and Click on PrintCloud Plus



Select the required Settings (Example: Black and White), Check the checkbox below that setting. This will enforce this setting to all users. Users will not be able to change settings on the operation Panel.



Print Color Mode is set to 'Black & White' and grayed out on the operation panel.

7 Limitations

PrintCloud Plus Limitation

- Up to 10 Jobs can be selected at a time to print.

File Conversion Limitations


- Refer to Appendix for Supported File Types by PrintCloud Service

Workplace Limitations

- Supported Browsers for User Site are:
 - Internet Explorer: 11 or later
 - Edge: Latest Version
 - Chrome: Latest Version
 - Firefox: Latest Version
- Limitations for Home Screen/Applications
 - Home: Maximum 20 for each profile, Max 32 characters for the name.
 - Applications: Maximum 18 for each home screen, Max 32 characters for the name
- User Management
 - Email address is unique in the system; same Email address cannot be used even if user belongs to different Tenants
 - Users belong to same tenant cannot set different time zones
 - User cannot change their login Email address, need admins assistance to change email address

General Limitations

- Once Administrator has logged in to a Tenant on MFP, administrator from another tenant cannot login to same MFP. Refer to guide on 'How to remove registered device'
- Back button inside application display screen must be used, instead for 'Back' button on the operation panel.



- Folder and File Search results varies from Cloud Service to Cloud Service, this depends on the Search API for each service.

8 Appendix

Supported File Types

jpeg, jpg, jpe, png, tif, tiff, gif

txt, html, htm

doc, docx, xls, xlsx, ppt, pptx

pdf

Open Office: odt, odp ods,